1. Package Content

Thank you for purchasing PLANET 24-Port 10/100Mbps PoE Web Smart Ethernet Switch, FNSW-2400PS. Terms of "Switch" in following section of this quick installation guide means the FNSW-2400PS.

Upon open the box of the Switch and carefully unpack it. The box should contain the following items:

- The PoE Web Smart Ethernet Switch x 1
- This Quick Installation Guide x 1
- User's Manual CD x 1
- Power Cord x 1
- Rubber Feet x 4
- Two Rack-mounting Brackets with Attachment Screws x 1

If any item is found missing or damaged, please contact your local reseller for replacement.

2. Requirements

The FNSW-2400PS provides remote Web interface for manage; the following equipments are necessary for further management.


- Workstation installed with Ethernet NIC (Network Interface Card)
- Workstations of subscribers running Windows XP/2003, Vista, Windows 7, MAC OS X, Linux, Fedora, Ubuntu or other platform compatible with TCP/IP protocols.
 - Above Workstation installed with Web Browser and JAVA runtime environment Plug-in.
- Ethernet Port connects with Network cables use standard network (UTP) cables with RJ-45 connectors.

It is recommended to use Internet Explore 7.0 or above to access FNSW-2400PS PoE Web Smart Ethernet Switch.

3. Start Web Management

The PLANET FNSW-2400PS provides a built-in browser interface. You can manage the Switch remotely by having a remote host with Web browser, such as Microsoft Internet Explorer, Apple Safari or Mozilla Firefox.

	2			
_	4	_		



-1-


The following shows how to startup the **Web Management** of the **Switch**, please note the Switch is configured through an Ethernet connection, make sure the manager PC must be set on the same **IP subnet address**, for example, PLANET default IP address of the Switch is **192.168.0.100** (the factory-default IP address), then the manager PC should be set at 192.168.0.x (where x is a number between 1 and 254, except 100), and the default subnet mask is 255.255.255.0.

4. Login the Managed Switch

- Use Internet Explorer 7.0 or above Web browser, enter IP address <u>http://192.168.0.100</u> (the factory-default IP address) to access the Web interface.
- When the following dialog box appears, please enter the default user name "admin" and password "admin". The login screen in Figure 4-1 appears.

Default IP Address: **192.168.0.100** Default User Name: **admin** Default Password: **admin**

FNSW-2400PS Web Smart Switch Welcome to PLANET FNSW-2400PS Switch
Copyright © 2011 PLANET Technology Corporation. All rights reserved.



3. After entering the user name and password, the Web main screen appears as Figure 4-2.

PLANET		
		10/100Mbps Ethernet Switch
Switch Menu		
🕈 🗀 Administrator	Welcome to PLANET FNSW-2400PS Web Smart Switch	
🕈 📮 Port Management		
VLAN Setting	PLANET Technology Corporation	
QoS Setting		
	11F, No. 96, Min-Chuan Road, Hsin-Tien,	
• 🗎 Spanning Tree	Taipei, Taiwan, R.O.C. Tel: 886-2-2219-9518	
• 🛄 Trunking	Fax: 886-2-2219-9528 Email: Sales@planet.com.tw	
DHCP Relay Agent		
Backup/Recovery		
• 🗎 Miscellaneous	Copyright © 2011 PLANET Technology Corporation. All rights reserved.	
SNMP Settings		
📲 Save Settings		
• 🛄 Logout		

Figure 4-2. Web Main Screen of FNSW-2400PS



802.3af 24-Port 10/100Mbps PoE FNSW-2400PS **Web Smart Ethernet Switch**





Quick Installation Guide



PLANET Technology Corp. 2011-A81180-000



 PDE
 BD2.3af
 RSTP
 SNMP
 VLAN
 IGMP

Now, you can use the Web management interface to continue the Switch management, please refer to the user's manual for more.



For security reason, please change and memorize the new password after this first setup.

5. Forgotten IP Address or Switch Login Password

To reset the IP address to the default IP Address **"192.168.0.100"** and the use name / password to factory default mode (default user name and password is **admin**). Press the hardware reset button at the front panel about 5 seconds. After the device is rebooted, you can login the management Web interface within the same subnet of 192.168.0.xxx and default user name / password.

	• P					24-Port 10/100Mbps PoE							
	2	4	6	8	• 10	12	14	16	• 18	20	22	• LNK/ACT 24	Web Smart Ethernet Switch
	-										•	Pat Is Use UNK/ACT	Reset
INISW-2400PS	1	3	5	7	9	11	13	15	17	19	21	23 PoE is Use	l l l l l l l l l l l l l l l l l l l
FNSW-2400PS	•	•	•	•	•	•	•	•	•	•	•	Pot in Use	

Hardware Reset

6. Customer Support

Thank you for purchasing PLANET products. You can browse our online FAQ resource at the PLANET Web site first to check if it could solve you issue. If you need more support information, please contact PLANET switch support team.

PLANET online FAQ : http://www.planet.com.tw/en/support/faq.php?type=1

Switch support team mail address : support_switch@planet.com.tw

Copyright © PLANET Technology Corp. 2011.

Contents subject to revision without prior notice.

PLANET is a registered trademark of PLANET Technology Corp. All other trademarks belong to their respective owners.