


**Lightning Arrester**

**WL-LTNA  
INSTALLATION GUIDE**




Please refer to the steps below and the picture to install WL-LTNA between External Antenna and N-Type Cable.

- Step 1: Connect your external Antenna to WL-LTNA.
- Step 2: Connect your N-type cable to WL-LTNA.
- Step 3: In the left side, you can see a screw, please use a low impedance ground cable to connect the screw and ground.

EM-WL-LTNAv1

**Lightning Arrester**

**WL-LTNA  
INSTALLATION GUIDE**




Please refer to the steps below and the picture to install WL-LTNA between External Antenna and N-Type Cable.

- Step 1: Connect your external Antenna to WL-LTNA.
- Step 2: Connect your N-type cable to WL-LTNA.
- Step 3: In the left side, you can see a screw, please use a low impedance ground cable to connect the screw and ground.

EM-WL-LTNAv1

**Lightning Arrester**

**WL-LTNA  
INSTALLATION GUIDE**




Please refer to the steps below and the picture to install WL-LTNA between External Antenna and N-Type Cable.

- Step 1: Connect your external Antenna to WL-LTNA.
- Step 2: Connect your N-type cable to WL-LTNA.
- Step 3: In the left side, you can see a screw, please use a low impedance ground cable to connect the screw and ground.

EM-WL-LTNAv1

**Lightning Arrester**

**WL-LTNA  
INSTALLATION GUIDE**




Please refer to the steps below and the picture to install WL-LTNA between External Antenna and N-Type Cable.

- Step 1: Connect your external Antenna to WL-LTNA.
- Step 2: Connect your N-type cable to WL-LTNA.
- Step 3: In the left side, you can see a screw, please use a low impedance ground cable to connect the screw and ground.

EM-WL-LTNAv1

**Lightning Arrester**

**WL-LTNA  
INSTALLATION GUIDE**




Please refer to the steps below and the picture to install WL-LTNA between External Antenna and N-Type Cable.

- Step 1: Connect your external Antenna to WL-LTNA.
- Step 2: Connect your N-type cable to WL-LTNA.
- Step 3: In the left side, you can see a screw, please use a low impedance ground cable to connect the screw and ground.

EM-WL-LTNAv1

**Lightning Arrester**

**WL-LTNA  
INSTALLATION GUIDE**




Please refer to the steps below and the picture to install WL-LTNA between External Antenna and N-Type Cable.

- Step 1: Connect your external Antenna to WL-LTNA.
- Step 2: Connect your N-type cable to WL-LTNA.
- Step 3: In the left side, you can see a screw, please use a low impedance ground cable to connect the screw and ground.

EM-WL-LTNAv1

**Lightning Arrester**

**WL-LTNA  
INSTALLATION GUIDE**




Please refer to the steps below and the picture to install WL-LTNA between External Antenna and N-Type Cable.

- Step 1: Connect your external Antenna to WL-LTNA.
- Step 2: Connect your N-type cable to WL-LTNA.
- Step 3: In the left side, you can see a screw, please use a low impedance ground cable to connect the screw and ground.

EM-WL-LTNAv1

**Lightning Arrester**

**WL-LTNA  
INSTALLATION GUIDE**



Please refer to the steps below and the picture to install WL-LTNA between External Antenna and N-Type Cable.

- Step 1: Connect your external Antenna to WL-LTNA.
- Step 2: Connect your N-type cable to WL-LTNA.
- Step 3: In the left side, you can see a screw, please use a low impedance ground cable to connect the screw and ground.

EM-WL-LTNAv1

**WARNING:**

1. Please look over the site before beginning any installation, and anticipate possible hazards.
2. Try to keep the antenna connection leave the power line away. People may be injured or killed if they are touching or holding any part of equipment when it contacts power lines.
3. Make sure all towers and masts are securely grounded, and electrical cables connected to antennas have grounded lightning arrestors.
4. Do not connect when a storm is near or when transmissions are occurring.

**Specification:**

|                            |                    |
|----------------------------|--------------------|
| Type:                      | Gas Discharged     |
| Frequency:                 | 0~6GHz             |
| Gain Loss:                 | Less then 0.5dB    |
| Maximum withstand current: | 20KA               |
| Connector Type:            | N male to N female |

PLANET Technology Corp.  
10F., No.96, Minquan Rd., Xindian Dist., New Taipei City 231, Taiwan (R.O.C.)  
Tel: 886-2-22199518 Fax: 886-2-22199528  
<http://www.planet.com.tw>

**WARNING:**

1. Please look over the site before beginning any installation, and anticipate possible hazards.
2. Try to keep the antenna connection leave the power line away. People may be injured or killed if they are touching or holding any part of equipment when it contacts power lines.
3. Make sure all towers and masts are securely grounded, and electrical cables connected to antennas have grounded lightning arrestors.
4. Do not connect when a storm is near or when transmissions are occurring.

**Specification:**

|                            |                    |
|----------------------------|--------------------|
| Type:                      | Gas Discharged     |
| Frequency:                 | 0~6GHz             |
| Gain Loss:                 | Less then 0.5dB    |
| Maximum withstand current: | 20KA               |
| Connector Type:            | N male to N female |

PLANET Technology Corp.  
10F., No.96, Minquan Rd., Xindian Dist., New Taipei City 231, Taiwan (R.O.C.)  
Tel: 886-2-22199518 Fax: 886-2-22199528  
<http://www.planet.com.tw>

**WARNING:**

1. Please look over the site before beginning any installation, and anticipate possible hazards.
2. Try to keep the antenna connection leave the power line away. People may be injured or killed if they are touching or holding any part of equipment when it contacts power lines.
3. Make sure all towers and masts are securely grounded, and electrical cables connected to antennas have grounded lightning arrestors.
4. Do not connect when a storm is near or when transmissions are occurring.

**Specification:**

|                            |                    |
|----------------------------|--------------------|
| Type:                      | Gas Discharged     |
| Frequency:                 | 0~6GHz             |
| Gain Loss:                 | Less then 0.5dB    |
| Maximum withstand current: | 20KA               |
| Connector Type:            | N male to N female |

PLANET Technology Corp.  
10F., No.96, Minquan Rd., Xindian Dist., New Taipei City 231, Taiwan (R.O.C.)  
Tel: 886-2-22199518 Fax: 886-2-22199528  
<http://www.planet.com.tw>

**WARNING:**

1. Please look over the site before beginning any installation, and anticipate possible hazards.
2. Try to keep the antenna connection leave the power line away. People may be injured or killed if they are touching or holding any part of equipment when it contacts power lines.
3. Make sure all towers and masts are securely grounded, and electrical cables connected to antennas have grounded lightning arrestors.
4. Do not connect when a storm is near or when transmissions are occurring.

**Specification:**

|                            |                    |
|----------------------------|--------------------|
| Type:                      | Gas Discharged     |
| Frequency:                 | 0~6GHz             |
| Gain Loss:                 | Less then 0.5dB    |
| Maximum withstand current: | 20KA               |
| Connector Type:            | N male to N female |

PLANET Technology Corp.  
10F., No.96, Minquan Rd., Xindian Dist., New Taipei City 231, Taiwan (R.O.C.)  
Tel: 886-2-22199518 Fax: 886-2-22199528  
<http://www.planet.com.tw>

**WARNING:**

1. Please look over the site before beginning any installation, and anticipate possible hazards.
2. Try to keep the antenna connection leave the power line away. People may be injured or killed if they are touching or holding any part of equipment when it contacts power lines.
3. Make sure all towers and masts are securely grounded, and electrical cables connected to antennas have grounded lightning arrestors.
4. Do not connect when a storm is near or when transmissions are occurring.

**Specification:**

|                            |                    |
|----------------------------|--------------------|
| Type:                      | Gas Discharged     |
| Frequency:                 | 0~6GHz             |
| Gain Loss:                 | Less then 0.5dB    |
| Maximum withstand current: | 20KA               |
| Connector Type:            | N male to N female |

PLANET Technology Corp.  
10F., No.96, Minquan Rd., Xindian Dist., New Taipei City 231, Taiwan (R.O.C.)  
Tel: 886-2-22199518 Fax: 886-2-22199528  
<http://www.planet.com.tw>

**WARNING:**

1. Please look over the site before beginning any installation, and anticipate possible hazards.
2. Try to keep the antenna connection leave the power line away. People may be injured or killed if they are touching or holding any part of equipment when it contacts power lines.
3. Make sure all towers and masts are securely grounded, and electrical cables connected to antennas have grounded lightning arrestors.
4. Do not connect when a storm is near or when transmissions are occurring.

**Specification:**

|                            |                    |
|----------------------------|--------------------|
| Type:                      | Gas Discharged     |
| Frequency:                 | 0~6GHz             |
| Gain Loss:                 | Less then 0.5dB    |
| Maximum withstand current: | 20KA               |
| Connector Type:            | N male to N female |

PLANET Technology Corp.  
10F., No.96, Minquan Rd., Xindian Dist., New Taipei City 231, Taiwan (R.O.C.)  
Tel: 886-2-22199518 Fax: 886-2-22199528  
<http://www.planet.com.tw>

**WARNING:**

1. Please look over the site before beginning any installation, and anticipate possible hazards.
2. Try to keep the antenna connection leave the power line away. People may be injured or killed if they are touching or holding any part of equipment when it contacts power lines.
3. Make sure all towers and masts are securely grounded, and electrical cables connected to antennas have grounded lightning arrestors.
4. Do not connect when a storm is near or when transmissions are occurring.

**Specification:**

|                            |                    |
|----------------------------|--------------------|
| Type:                      | Gas Discharged     |
| Frequency:                 | 0~6GHz             |
| Gain Loss:                 | Less then 0.5dB    |
| Maximum withstand current: | 20KA               |
| Connector Type:            | N male to N female |

PLANET Technology Corp.  
10F., No.96, Minquan Rd., Xindian Dist., New Taipei City 231, Taiwan (R.O.C.)  
Tel: 886-2-22199518 Fax: 886-2-22199528  
<http://www.planet.com.tw>

**WARNING:**

1. Please look over the site before beginning any installation, and anticipate possible hazards.
2. Try to keep the antenna connection leave the power line away. People may be injured or killed if they are touching or holding any part of equipment when it contacts power lines.
3. Make sure all towers and masts are securely grounded, and electrical cables connected to antennas have grounded lightning arrestors.
4. Do not connect when a storm is near or when transmissions are occurring.

**Specification:**

|                            |                    |
|----------------------------|--------------------|
| Type:                      | Gas Discharged     |
| Frequency:                 | 0~6GHz             |
| Gain Loss:                 | Less then 0.5dB    |
| Maximum withstand current: | 20KA               |
| Connector Type:            | N male to N female |

PLANET Technology Corp.  
10F., No.96, Minquan Rd., Xindian Dist., New Taipei City 231, Taiwan (R.O.C.)  
Tel: 886-2-22199518 Fax: 886-2-22199528  
<http://www.planet.com.tw>